

DATE: October 1, 2004; Revised September 14, 2006¹

TO: Office of Drinking Water Technical Staff

THROUGH: J. Wesley Kleene, Ph.D., P.E., Director
Office of Drinking Water

FROM: Richard M. Puckett, P.E., Chairman
Membrane Technology Committee

SUBJECT: Water – Design and Construction – Treatment
Hollow Fiber, Positive Pressure Driven
Microfiltration and Ultrafiltration Membrane Filtration Technology

DELETE: WM 723 and WM 830

RELATED: WM 844 (Special Notices), WM 851 (Sanitary Surveys), and
WM 869 (Turbidity Treatment Technique for Other Filtration Technologies)

KEY REVISIONS:

- Adds a 30 minute chlorine contact time for VRC and inactivation,
- Clarifies deposition and suspension modes in hydraulic configurations,
- Clarifies the use of DIT sensitivity calculations and actual LRV,
- Clarifies the NTU monitoring and other monitoring requirements,
- Adds requirements to the EDS,
- Clarified when modifications would require compliance for existing systems,

SUMMARY STATEMENT:

This memorandum provides guidance for the use of membrane filtration technology for pathogen and turbidity removal. Under the guidelines of this working memo, conventional process approval procedures for microfiltration and ultrafiltration, hollow fiber, positive pressure driven membrane filtration technology may be followed (§12 VAC 5-590-200). This memorandum also provides guidance for the preparation of waterworks operation permits and for surveillance of existing and new membrane filtration systems.

TABLE OF CONTENTS

I.	PURPOSE	2
II.	MEMBRANE FILTRATION DEFINITION	2
III.	<i>GIARDIA</i> CYSTS AND <i>CRYPTOSPORIDIUM</i> OOCYSTS REMOVAL CREDITS	3
IV.	VIRUS REDUCTION CREDIT AND REDUCTION REQUIRED	3
V.	OVERVIEW OF THE VARIOUS MEMBRANE FILTRATION PROCESSES	3
VI.	HYDRAULIC CONFIGURATIONS	3
VII.	DESIGN AND OPERATION ISSUES	4
VIII.	PRODUCT SPECIFIC CHALLENGE TEST	4
IX.	QUALITY CONTROL RELEASE VALUE	5
X.	DIRECT INTEGRITY TEST	6

¹ Previously WM 703 dated March 3, 1993 and WM 723 dated August 8, 1994

XI.	DIAGNOSTIC TESTING	7
XII.	CONTINUOUS INDIRECT INTEGRITY MONITORING	8
XIII.	INSTRUMENTATION	9
XIV.	RELIABILITY	12
XV.	CLASS OF OPERATOR AND ATTENDANCE	12
XVI.	PERFORMANCE VERIFICATION	13
XVII.	OPERATION AND MAINTENANCE MANUAL	14
XVIII.	WATERWORKS OPERATION PERMIT SPECIAL CONDITIONS	14
XIX.	REPORTING AND RECORDKEEPING	15
XX.	EXISTING MEMBRANE FILTRATION SYSTEM.....	16

APPENDICES

APPENDIX A - PRELIMINARY ENGINEERING REPORT

APPENDIX B - DEMONSTRATION STUDIES

APPENDIX C - INSTRUCTIONS FOR USING THE MONTHLY OPERATION REPORT FORM

APPENDIX D – MONTHLY OPERATIONS REPORT

APPENDIX E – WORKING MEMORANDUM REVISION DETAILS

I. PURPOSE

The purpose of this working memo is to provide guidance for the use of membrane filtration technology for pathogen and turbidity removal. Under the guidelines of this working memo, conventional process approval procedures for microfiltration and ultrafiltration, hollow fiber, positive pressure driven membrane filtration technology may be followed (§12 VAC 5-590-200). Under the guidelines of this working memo, a provisional waterworks operation permit is not required (§12 VAC 5-590-290). Such guidance is given in the context of the following:

- Membrane filtration for pathogen removal is still in the early developmental stages in the United States. Adequately documented, full-scale experience is not widespread.
- The United States Environmental Protection Agency (EPA) has developed regulations containing design and implementation conditions for the degree of credit awarded for removal of *Cryptosporidium*.
- The United States Environmental Protection Agency (EPA) finalized the Membrane Filtration Guidance Manual, dated November 2005, that provides additional information and procedures for meeting these criteria. This working memo will need to be reviewed and adjusted as necessary upon incorporation of the LT2ESWTR into the *Waterworks* Regulations. The EPA regulations and guidance are available at <http://www.epa.gov/safewater/disinfection/lt2/compliance.html>.

II. MEMBRANE FILTRATION DEFINITION

Membrane filtration is defined as a pressure-driven separation process in which particulate matter larger than 1 µm is rejected by a non-fibrous, engineered barrier primarily through a size exclusion mechanism and which has a measurable removal efficiency of a target organism that can be verified through the application of a direct integrity test (DIT). This working memo is intended to include the common membrane technology classifications of microfiltration (MF) and ultrafiltration (UF) using hollow fibers. This working memo does not cover other membrane technologies (such as vacuum-driven hollow fiber membranes), other membrane configurations (such as spiral wound membranes), or membranes applied for purposes other than turbidity and suspended pathogen removal (such as removal of dissolved solids).

For consistency two definitions are provided:

- Module means the smallest component of a membrane unit in which a specific membrane surface area is housed in a device with a filtrate outlet.
- Unit means a group of membrane modules that share common valving which allows the unit to be isolated from the rest of the system for the purpose of integrity testing or other maintenance.

The United States Environmental Protection Agency (USEPA), *Membrane Filtration Guidance Manual* glossary should be consulted for additional definitions.

III. *GIARDIA* CYSTS AND *CRYPTOSPORIDIUM* OOCYSTS REMOVAL CREDITS

Under the guidelines of this working memo, the maximum *Giardia* cysts and *Cryptosporidium* oocysts log removal credit (LRC) is 3-log for each.

IV. VIRUS REDUCTION CREDIT AND REDUCTION REQUIRED

Virus removal credit by membrane filtration is zero.

Virus reduction post membrane filtration is required so that virus inactivation and other microbial minimum treatment requirements are achieved. A 4-log inactivation of viruses by disinfection treatment is required and a minimum 30 minute chlorine contact time is required.

V. OVERVIEW OF THE VARIOUS MEMBRANE FILTRATION PROCESSES

The EPA *Membrane Filtration Guidance Manual* contains an overview of the various membrane filtration processes, including descriptions of the various classes, membrane material, geometry, module construction, driving forces, basic principles of design and operation, and hydraulic configuration(s). Emphasis is given to the manner in which each of these characteristics relates to membrane filtration applied for pathogen removal.

VI. HYDRAULIC CONFIGURATIONS

Overview of hydraulic configurations:

- Hollow fiber flow path can be either inside-out or outside-in.
- Hydraulic configuration is either deposition mode or the suspension mode.
- The ratio of the concentration of particles in suspension on the feed side of the membrane to the concentration of particles in the influent feed is characterized by the volumetric concentration factor (VCF). In any mode of operation, the VCF shall be ≤ 4 .
- Deposition mode systems, commonly called dead-end or direct filtration systems do not concentrate suspended solids on the feed side of the membrane. In these systems, particulate matter in the feed water is deposited on the membrane surface and held in place by the transmembrane pressure and there have a $VCF = 1$.
- The deposition mode may include a periodic back pulse with air, filtrate, and/or oxidants to dislodge particles trapped on the membrane surface. The VCF will equal 1 if these dislodged particles are removed from the system immediately after the back pulse. Without removing these dislodged particles, the VCF should be determined as operating in the suspension mode (see the EPA Guidance Manual).
- In the suspension mode, hydraulic force tangential to the membrane surface keeps particulate matter in suspension resulting in the feed side particulate concentration being higher than the influent feed concentration. The VCF will vary depending on the hydraulic configuration.

- Crossflow is a type of suspension mode operation. Air and/or water are continuously or intermittently applied through a recirculation loop, as a scouring force to keep particles suspended or to re-suspend deposited particles. Accumulated solids must be removed from the system during the backwash cycle. The maximum volumetric concentration factor shall be 4 over the course of any filtration cycle.
- Feed-and-bleed is a type of suspension mode operation similar to crossflow in that particles are held in suspension on the feed side of the membrane while a continuous concentrate waste stream removes particles from the system. Backwashing essentially removes all the particles from the system. As a result the VCF is reduced to zero at the completion of each backwash cycle. The maximum VCF shall be 4 at the end of the filtration cycle.

VII. DESIGN AND OPERATION ISSUES

The EPA *Membrane Filtration Guidance Manual* should be consulted for system design and operation of membrane unit processes including pretreatment, backwashing, chemical cleaning, integrity testing, and post-treatment. Additionally the same section of the *Guidance Manual* discusses some of the most significant design issues associated with flux, water quality, temperature compensation, cross connection control, and reliability. Residuals and concentrate disposal are also discussed.

Construction sequence, customer service, and waste disposal must be addressed. Waste disposal includes wastes generated from removal of the membrane preservation solution, flushing the system prior to membrane installation, initial system disinfection, and performance verification period operation.

Membrane filtration units may be fitted with block and bleed valve arrangements or removable spools to eliminate the potential for backflow. See the same section of the *Guidance Manual* for additional information.

All membrane materials and associated piping, etc. must be certified NSF/ANSI Standard 61.

Chemicals used in any membrane unit cleaning process shall be NSF 60 certified or shall otherwise be acceptable to the Commissioner.

Design and operational issues to be evaluated are included in Appendix A, Preliminary Engineering Report section. This list is not all inclusive.

VIII. PRODUCT SPECIFIC CHALLENGE TEST

Removal efficiency of microbial pathogens of concern shall be established through a product specific challenge test. Specific and detailed challenge test criteria must be followed. Challenge testing demonstrates the removal efficiency a membrane module is capable of achieving. Removal efficiency is expressed as a log removal value (LRV). Based on the *Membrane Filtration Guidance Manual* challenge testing criteria, a membrane module can potentially demonstrate up to 6.5-log removal of the challenge particulate if removed to the detection limit. Only those specific products where challenge testing results calculate to 5.5-log removal or greater will be considered for acceptance.
($LRV_{C-Test} \geq 5.5\text{-log}$).

The EPA *Membrane Filtration Guidance Manual* provides specific criteria and procedures for meeting the challenge test criteria. The EPA *Membrane Filtration Guidance Manual* or equivalent criteria shall be used for the following challenge test requirements:

- Full-scale vs. small-scale module testing
- Small-scale module material identical to full-scale module material
- Appropriate challenge particulates
- Challenge particulate concentrations
- Test operating conditions
 1. Maximum recovery
 2. Representative hydraulic configuration and VCF
 3. Maximum flux
- Calculation of removal efficiency
- Establishment of a quality control release value (QCRV) for a non-destructive performance test (NDPT)

Challenge testing must be conducted using *Cryptosporidium* oocysts or a surrogate that has been determined to be removed no more efficiently than *Cryptosporidium* oocysts. Indirect water quality measurements such as turbidity, particle counting, or conductivity shall not be used to determine removal efficiency of pathogens. The concentration of the organism or surrogate used during challenge testing must be determined using a method capable of discretely quantifying the specific challenge particulate used in the test.

The challenge test protocol and results must demonstrate the removal efficiency. Previously conducted challenge testing demonstrating acceptable removal and not significantly deviating from the *Membrane Filtration Guidance Manual* challenge test criteria will be considered. The challenge test protocol and results used to demonstrate removal efficiency acceptance must be submitted as part of the Preliminary Engineering Report.

Modified membrane modules must be retested if the modifications may affect the membrane characteristics, removal efficiency, or the nondestructive performance test NDPT results and associated quality control release value QCRV. Some examples of modifications requiring retesting include but are not limited to: membrane material, membrane backing material, pore size distribution, porosity, permeability, or symmetry. Modifications to the hydraulic configuration of a filtration system will require retesting if the concentration of suspended solids on the feed side (VCF) may be higher. An example of an increased VCF is when the configuration was originally tested in the dead end (deposition mode) and the proposed configuration is crossflow (suspension mode).

The product specific challenge test report must include the methodology used in determining the QCRV for the NDPT. The QCRV must be sufficient to justify a 5.5 LRV and a 3µm resolution.

IX. QUALITY CONTROL RELEASE VALUE

The NDPT and QCRV are necessary because the challenge test criteria do not require that every membrane module be subjected to challenge testing. A non-destructive performance test, e.g., bubble point test or pressure decay test may be applied to each production membrane module in order to verify removal efficiency of those that did not undergo challenge testing. A quality control release value (QCRV) must be established for the NDPT that is directly related to the minimum removal efficiency capability of the membrane filtration process of 5.5-log removal as demonstrated during challenge testing. Membrane modules that do not meet the established QCRV are not eligible for the removal credit demonstrated during challenge testing.

Each module shall be accompanied by documentation of the successful application of the product specific quality control release value. The documentation shall be provided for each module to the waterworks owner or its representative for acceptance.

X. DIRECT INTEGRITY TEST

In order to receive *Giardia* cyst and *Cryptosporidium* oocyst removal credit, the removal efficiency of a membrane filtration process must be routinely verified during operation using direct integrity testing. The direct integrity test must be applied to the physical elements of the entire membrane unit, including membranes, seals, potting material, associated valves and piping, and all other components which could result in contamination of the filtrate under compromised conditions.

The currently acceptable direct integrity test is a pressure-based test based on bubble point theory, which involves applying a positive pressure to one side of a wetted membrane barrier and monitoring for pressure loss or pressure decay in order to establish whether an integrity breach is present. The DIT system must be capable of preprogrammed automatic operation or manual initiation.

The direct integrity test applied to a membrane unit must meet performance criteria for resolution, sensitivity, and frequency as follows:

- Resolution: The direct integrity test must be responsive to an integrity breach on the order of 3 μm or less.
- Sensitivity: The direct integrity test must be able to verify a 4.0-log removal value (LRV_{DIT}).
- Frequency: A direct integrity test must be conducted, as a minimum, once each day on each membrane unit that is in operation, even if the unit is operated for only a fraction of the day . Each unit should be tested at approximately the same time each day.

The DIT sensitivity is primarily a function of the smallest, reliably measurable response associated with an integrity breach the equipment can detect, referred to as the threshold response.

Sensitivity may also be affected by the diffusion of air through the water in the wetted pores of an integral membrane, referred to as the baseline decay or diffusive losses.

The DIT sensitivity must be such that at least a 4.0-log removal value (LRV_{DIT}) can be reliably verified. The LRV_{DIT} is calculated using the threshold response and other parameters associated with the membrane unit design (GM Eq. 4.9). If diffusive losses are expected to have a significant impact on the sensitivity calculation, the manufacturer should be able to provide the baseline pressure decay rate or diffusion coefficient for the membrane so that the diffusive losses can be calculated.

Control limits are calculated using the same DIT sensitivity principles. An alarm condition control limit and a shutdown control limit, both in terms of pressure decay rate, shall be established and programmed into the data acquisition system. The alarm condition shall be based on a $\text{LRV} = 3.5$. The shutdown control limit shall be based on the LRV of 3.0. Exceeding the shutdown control limit requires the unit to be taken off line for diagnostic testing and repair.

The same DIT sensitivity principles (Eq. 4.9) can be used to verify the actual, operating LRV during the performance verification period and beyond.

Direct integrity test parameters:

- Use of the latest edition of ASTM D 6908-03 Standard, Practice A, Pressure Decay Test for DIT procedures is required with the following stipulations:
 1. In section 9.1.5, the time for the decay rate determination shall be at least five minutes
 2. In section 9.1.7, the measured pressure decay (ΔP) rate may be corrected by subtracting the pressure decay due to diffusive air flow from the measured pressure decay
 3. In section 9.1.8, the more conservative approach should be taken assuming all pressure decay is related to integrity
 4. In section 9.3, integrity test pressure (P_{test}) should be calculated using conservative membrane property parameters in determining the minimum required test pressure required to meet the $3\mu\text{m}$ resolution criteria. Intrinsic properties of manufactured membrane pores are more than likely not the same as the properties of defects or tears or oversized holes in the membrane material. Therefore, the conservative values of pore shape, contact angle, and surface tension must be used. Additionally, any hydrostatic backpressure must be included in calculating the minimum test pressure. Using the conservative values of $K=1$, $\theta=0$, and $s=74.9$ dynes/cm @ 5 degrees C results in $P_{\text{test}} = 14.5$ psi + maximum hydrostatic backpressure.

If the pressure at the end of the test is below the pressure calculated above (that is, psi necessary to meet the resolution criteria of responding to a breach of $\leq 3\mu\text{m}$) then the test failed. Calculated test pressure should be increased to account for some baseline decay so as to ensure adequate applied pressure throughout the duration of the test.

As a result, the minimum test pressure must be:

$$P_{\text{test}} = 14.5 \text{ psi} + \text{hydrostatic backpressure} + \text{baseline decay}.$$

- DIT parameters must be viewable by the operator, as follows:
 1. Initial pressure
 2. Stabilization period (if applicable)
 3. Test pressure (starting pressure, P_{test})
 4. Final pressure
 5. Decay rate determination duration
 6. Decay rate (ΔP)
 7. LRV (optional)

Direct integrity test optimization and control limits:

- Optimization – To achieve optimized removal of particulate pathogens, the units should be operated at or below the DIT pressure decay rate (psi/min) corresponding to a LRV of 4.0.
- Alarm – To alert the operator of potential problems, an alarm must be energized and the operator informed when the DIT pressure decay rate (psi/min) corresponding to an LRV of 3.5 is reached.
- Shut down – Any membrane unit reaching the DIT pressure decay rate (psi/min) corresponding to a LRV of 3.0 (independent of any indirect monitoring data) must be taken off line immediately, for diagnostic testing and subsequent repair.
- Operating a single unit or more at a DIT pressure decay rate (psi/min) corresponding to a LRV of < 3.0 may result in a boil notice being issued.

XI. DIAGNOSTIC TESTING

A means shall be provided to isolate a compromised module or fiber or both. A means to visually inspect modules while simultaneously conducting the DIT must be provided. Alternatively, sonic

testing equipment providing a relative accelerometer reading shall be provided where visual inspection cannot be performed. Sonic testing equipment to supplement visual inspections is recommended.

Where membrane modules must be removed for repair, single module bubble testing apparatus to facilitate testing of removed modules shall be provided.

Some diagnostic testing procedures of modules or units after a shutdown alarm condition or other unit isolation diagnostic procedures will require filter-to-waste capabilities.

Consideration must be given to providing adequate space and equipment for removal of modules for inspection and testing.

XII. CONTINUOUS INDIRECT INTEGRITY MONITORING

Continuous indirect integrity monitoring equipment shall be provided as a surrogate measure of membrane unit integrity for operational control and shall be provided to determine compliance with the turbidity treatment technique.

Continuous indirect integrity monitoring is required between direct integrity testing to provide some measure of performance assessment. Continuous reading and recording instrumentation systems shall be provided for filtrate turbidity monitoring of each unit by the most sensitive method of turbidity monitoring available. Currently this method is by laser nephelometers. Other turbidity monitors will be evaluated and approved on a case-by-case basis. "Continuous" means monitoring at a frequency of no less than once every 15 minutes.

The ability to multiplex these instruments may help to minimize the associated cost of utilizing laser nephelometers. In multiplexing, multiple sensors are connected to a single laser light source, detector, and control system via fiber optics. Sensors can be attached to monitor the filtrate from each membrane unit or individual membrane modules, if desired.

Turbidity control limits are established based on the consistent performance of most MF and UF systems producing filtrate water with turbidities in the 0.03 to 0.07 NTU range as measured by conventional tungsten-filament lamp nephelometers (EPA GM). An alarm condition control limit, a DIT trigger control limit, and a shutdown control limit, shall be established and programmed into the data acquisition system.

Indirect integrity monitoring, filtrate turbidity optimization and control limits:

- Optimization – To achieve optimized removal of particulate pathogens, the units must be operated at or below a filtrate turbidity of 0.1 NTU
- Alarm – To alert the operator of potential problems, an alarm must be energized and the operator informed when the filtrate turbidity of any unit exceeds 0.1
- DIT triggered - Whenever two consecutive, 15 minute turbidity readings exceed 0.15 NTU for any one unit, the DIT is automatically initiated on that unit.
- Shut down –Any membrane unit filtrate turbidity reaching 0.3 NTU or greater (independent of any direct monitoring data) must be taken off line immediately for necessary diagnostic testing and subsequent repair.

Turbidity treatment technique compliance is based on a filtered water turbidity of less than or equal to 0.3 NTU in at least 95% of the measurements taken each month and . the turbidity level of representative samples of a system's filtered water must at no time exceed 1 NTU. Neither

combined filtrate nor entry point monitoring, by continuous reading and recording of turbidity is required for turbidity treatment technique compliance. Daily grab sample analysis by a bench nephelometer of the entry point turbidity is required for turbidity treatment technique compliance. See Working Memo 869 for additional details.

Filtered water (entry point) turbidity levels exceeding 1.0 NTU in conjunction with other factors warrant the issuance of a boil water notice. See Working Memo 844 for additional details.

XIII. INSTRUMENTATION

- a. Continuous reading and recording instrumentation systems shall be provided for filtrate turbidity monitoring of each unit as described in Section XII.
- b. Continuous reading instrumentation systems shall be provided as indicated below:
 - o Source water turbidity monitoring by, as a minimum, tungsten-filament lamp nephelometers
 - o Feed water turbidity monitoring by, as a minimum, tungsten-filament lamp nephelometers (between prefiltration and each membrane unit) is recommended.
 - o Pressure drop across raw water prefiltration or prefiltration on the membrane unit, as appropriate
 - o Pressure drop across the membrane modules, i.e. transmembrane pressure
 - o Filtrate turbidity monitoring of each unit by laser nephelometers or particle counters in combination with tungsten-filament lamp nephelometers
 - o Date, time, and results of the direct integrity test on each unit

Continuous reading instrumentation system shall be provided at the waterworks entry point to the distribution system for disinfectant residual.

Continuous reading instrumentation means an electronic sensor continuously reads the parameter and the parameter is displayed in real time. Continuous recording means one data point is stored in memory or printed at least every 15 minutes. The one data point that is stored or printed is a snapshot of the parameter at that time; it is not an average of previous data points.

Continuous reading instrumentation requires a continuous flow through the instrument sensor. During periods of shut down, backwashing, chemical cleaning, or other maintenances activities, the flow through the sensor may stop and the instrument sensor may go dry resulting in erroneous readings. These erroneous readings may create an alarm condition and shutdown the unit or prevent its restarting. Provisions should be included to prevent sensors from going dry.

- c. Air Entrainment Error
Air entrainment error caused by air bubbles being introduced into the system either during production, backwashing, chemical cleaning, or integrity testing may be falsely detected as particulate matter, artificially increasing the instrument reading. Consequently, after a backwash cycle or chemical cleaning (particularly if air is utilized in the process), instrument measurements may not be representative of filtrate quality until any entrained air is purged from the system. This purge time will vary between different membrane filtration systems

and their respective backwash or chemical cleaning practices. Bubble traps may be employed to minimize or eliminate this error.

If removal of entrained air error is unsuccessful, the PLC may be programmed to verify an alarm or shutdown operational control condition immediately following an operation resulting in air entrainment so that the DIT is not triggered. Significant and continuous air entrainment problems will be addressed on a case by case basis.

d. Computers and SCADA

- Automated systems used to display and record data or control functions and that are connected to computers or networks with an internet link or that use a radio system shall have sophisticated encryption to prevent hacking.
- A backup power supply shall be provided to allow orderly shutdown of the computer system and prevent corruption of data. The protection shall cover every connection to all outside service providers such as power, cable, telephone, DSL, ISDN, etc.
- Adequate hardware shall be in place to allow a high degree of SCADA and computer system reliability and data security. Acceptable methods of meeting this requirement include:
 1. Providing side-by-side PCs capable of performing the same tasks, with the ability to rotate the operation and monitoring tasks between the two PCs, and with these PCs having mirrored hard drives or
 2. Installing duplicate mirrored hard drives in a single PC.
 - Adequate hardware and facilities shall be provided for data archiving. Providing the means to back-up data stored on hard disk drives to removable media on a daily basis and to maintain a back-up copy of archived data at a secure off-site location would meet this requirement.
 - SCADA and computer systems shall have adequate protection from voltage surges and spikes on the power supply and external data links.
 - Except for local displays and sensors designed for the environment, all electronic elements shall be located in an area free of excessive moisture, corrosive chemicals or excessive heat or shall be protected by an appropriately rated NEMA enclosure.
 - SCADA and computer systems used to meet the continuous recording requirements of the *Waterworks Regulations* shall record an observation on a minimum frequency of once per quarter hour, unless a greater recording frequency is required.
 - SCADA and computer systems used to meet the indicating and recording requirements of the *Waterworks Regulations* shall provide dedicated and continuous displays that show a minimum 24-hour trend of results for each parameter. The display panel(s) shall be located in an area where it can be routinely viewed by the operators. Sufficient display panels and software should be provided to allow the data to be observed without changing screens. However, if changing screens is necessary, then the displays of the required data must be easily accessible without excessive scrolling through multiple screens.
 - In the event of computer malfunction, all mandatory continuous in-line analyzers shall feature a display of the test results that is independent of any central computerized data system. Providing a separate display at each in-line unit would meet this requirement.
 - Manual Operation: Waterworks pumps, chemical feeders and other essential electrical equipment controlled through a SCADA or an automated control system shall have the capability for independent manual operation through a HOA switch.

Laboratory Instrumentation

Laboratory type, bench instrumentation units shall be provided as necessary to perform daily grab samples, comparisons of the continuous instrumentation, and provide for substitution of continuous reading where equipment is out of service. Bench units shall include turbidity, disinfectant residual, temperature, and pH.

f. Flow Rate Measurement

Flow measuring equipment for measuring or calculating the following:

- Source water, gpm and totalized
- Filtrate from each unit, gpm and totalized
- Flux at each unit
- Recirculation at each unit, % of feed flow or volume, if applicable
- entry point, gpm and totalized
- waste

g. Alarms and Automatic Shutdown

An alarm system shall be provided which will report alarm conditions and will shutdown the treatment plant and entry point flow. All alarm conditions shall be reported to a location manned 24 hours per day or activate an auto-dialer. The following alarm and shut down set point conditions shall be provided and will be determined on a case-by-case basis:

- Source water turbidity
- Feed water turbidity – where appropriate
- Low feed water flow
- Filtrate turbidity from each unit exceeding operational control criteria
- Membrane direct integrity test exceeding operational control criteria
- Excessive transmembrane pressure at each unit
- Entry point disinfectant residual, high and low
- Low air pressure

Where the membrane may be easily damaged or rendered inoperable due to excess feed water turbidity or debris, feed water monitoring equipment and alarm and shutdown set points shall be required for each unit. The alarm and shutdown set points will be determined on a case-by-case basis with the manufacturer's warranty considered.

h. Sample Taps

Sample taps shall be provided to monitor the following:

- source water
- source water storage tank effluent
- feed water after prefiltration
- filtrate from each membrane unit
- combined filtrate from all units
- point of entry
- Additional sample taps to monitor the presence of cleaning solutions used in either the backwash or cleaning operations.

i. Pressure Gauge Connections

At each location of a pressure transducer, a ¼ inch diameter NPT pressure gauge connection shall be provided to facilitate the connection of a portable, pocket type test gauge.

j. Pressure Gauge

A portable pocket type pressure gauge of the correct range and accuracy for the application and with the capability of being calibrated shall be provided to check the pressure transducers installed on the membrane units.

XIV. RELIABILITY

The need for treatment units on line, units in standby, duplication of units, and components or spare parts on hand or readily available will be decided on a case-by-case basis.

The number of membrane units will be a function of the overall waterworks design and storage capacity and the design maximum daily demand. Multiple membrane units should be provided where design capacity exceeds 0.5 MGD. Two units shall be provided where design capacity exceeds 2 MGD.

FOR GROUNDWATER OR SURFACE INFLUENCED GROUNDWATER SOURCES, CONTINUOUS WITHDRAWAL OF SOURCE WATER MUST BE CONSIDERED WHEN SIZING TREATMENT FACILITIES. THE SAFE YIELD OF WELLS AS ESTABLISHED BY CONVENTIONAL 48-HOUR YIELD AND DRAWDOWN TESTING, IS GENERALLY NOT BASED ON CONTINUOUS PUMPING AND MAY REQUIRE REDUCING THE DESIGN SAFE YIELD TO FACILITATE THE CONTINUOUS OPERATION OF A MEMBRANE PLANT.

Redundancy of pumps, motors, chemical feeders, etc., shall be in accordance with the applicable sections of the *Waterworks Regulations*, Manual of Practice.

The membrane treatment plant electrical system and essential electronic components should be closely evaluated for reliability. The environment the electrical system and essential electronic components are subjected to must be addressed by use of appropriate enclosures and environmental control. The need for additional filtering, voltage regulation, surge protection, interference protection, and etc., must be addressed.

Waterworks with greater than one day of domestic storage may not need dual parallel units. Where single units are used in conjunction with excess domestic storage, replacement components and spare parts must be on hand or readily available. As a minimum, a spare programmable logic controller (PLC) shall be readily available.

Appurtenances should be provided and pumping rates should be controllable to facilitate operation with a few modules removed or a membrane unit out of service.

Appurtenances would be necessary to cap-off the module location or isolate the membrane housing from the unit when one or more modules are removed or not in use.

Special consideration shall be given in the design of the building for equipment accessibility, piping locations, noise abatement, and vibration insulation.

XV. CLASS OF OPERATOR AND ATTENDANCE

a. Class and Attendance

Class and attendance will be in accordance with the *Waterworks Regulations*, Section 12 VAC 5-590-460 Personnel. These attendance requirements take into consideration the unattended automatic start-stop operation of membrane treatment units.

For new waterworks or waterworks employing membrane filtration for the first time, it is strongly recommended that the responsible charge operator be employed prior to construction of the system. Being at the facility during construction will provide maximum familiarity with the new technology.

b. Minimum Class

A minimum of a Class IV operator will be required to give attendance at the waterworks each day of operation for sufficient time to perform necessary monitoring and process evaluation, and to make any process adjustments deemed necessary. The necessity of public health protection, the complexity of pretreatment, changing or poor source water quality, and permitted capacity will necessitate the operator class being upgraded to Class III or higher.

- A Class IV operator must respond to any alarm-generated shutdown prior to restarting.
- A Class IV operator must be on site to manually start the chemical cleaning process.
- Daily attendance means physically at the plant every day when the plant is scheduled to operate.
- A Class IV must be on call when the plant is scheduled to operate.

XVI. PERFORMANCE VERIFICATION

a. Initial Start-Up

Flushing the membrane preservation solution from the modules and the system must be completed prior to initial disinfection. Initial system disinfection of the entire system, including both feed and filtrate piping, must include recirculation of the disinfectant solution through the system. The disinfectant solution used must be compatible with the membrane material. Upon completion of disinfection, the entire system, including the membranes, should be thoroughly flushed. The flushing and disinfection steps are complete when there is no detectable disinfectant residual and subsequent bacteriological sampling indicates the absence of Coliform organisms. ANSI/AWWA Standards C 651, C 652, and C 653 provide guidance for disinfecting waterworks.

Initially, the direct integrity test shall be conducted two to four times per day until the results stabilize. False positive direct or indirect integrity test results can be minimized by first characterizing typical system performance under a variety of operating conditions (such as after a backwash) and subsequently programming the data acquisition system to account for regularly occurring data aberrations of previously quantified magnitude and duration that are known not to represent an integrity problem, even if operational control performance criteria or integrity testing performance criteria are exceeded.

b. Thirty-Day Start-Up Period

Upon completion of construction of the membrane treatment facility and the initial start-up procedures, a performance verification period of approximately 30 days shall start. The verification period shall include at least one period of 48 hours of continuous operation.

During the performance verification period, the following shall be confirmed or verified, as appropriate, and documented:

- Design criteria of the specifications

- Performance requirements of the specifications
- Design capacity
- Design flux
- Integrity testing optimization and control limits
- Indirect integrity testing performance criteria
 - Alarm set point
 - DIT trigger set point
 - Shutdown set point
- Direct Integrity testing performance criteria
 - Frequency
 - Resolution
 - Sensitivity
 - Baseline decay
 - Alarm set point
 - Shutdown set point
- Backwash initiation and termination criteria
- Chemical cleaning initiation and termination criteria
 - Operator training as required by the specifications

c. Engineer's Statement of Completion of Construction

Performance must be verified by a licensed engineer prior to issuance of the waterworks operation permit. The performance verification period report shall be part of the engineer's substantial completion statement. The data contained in the report will be used in developing the waterworks operation permit, special conditions in section XVIII.

XVII. OPERATION AND MAINTENANCE MANUAL

The specifications shall include a requirement that a detailed, site specific, Operation and Maintenance Manual shall be provided by the engineer directly to the waterworks owner (ODW will provide technical assistance). The operator in responsible charge should have sufficient time to review the O & M Manual prior to the manufacturer's onsite training and thirty-day start up period.

The manufacturer supplied Operation and Maintenance Manual shall contain readily understood information on the recommended or required maintenance requirements for each piece of equipment. The manual shall also contain readily understood procedures for the proper operation of the membrane units and associated appurtenances including software user instructions. Additionally, the manual shall contain a trouble shooting guide. The manual shall identify specific equipment or software issues which the owner or the operator in responsible charge has no access to for operation and maintenance purposes. The manual shall be specific as to potential damage or any warranty issues involved. Additionally, the owner shall be advised which O&M issues must be addressed through a service call.

The *Environmental Technology Verification Protocol* prepared by the NSF and the EPA, contains detailed recommendations for O&M Manual criteria. The publication is available at <http://www.epa.gov/etv/>. Additionally, the *EPA Membrane Filtration Guidance Manual* should be consulted for operational issues to include in the O&M Manual.

XVIII. WATERWORKS OPERATION PERMIT SPECIAL CONDITIONS

These operational control criteria and additional operational requirements are imposed on the issuance of the permit to operate as enforceable operational conditions.

a. Operational Control Criteria

The following shall be included in the Waterworks Operation Permit, Engineering Description Sheet as special conditions:

Operational Control Parameter	Alarm Set Point	Shutdown Set Point
Source water turbidity		
Feed water turbidity (optional)		
Direct integrity test	psi/min equivalent to LRV of 3.5	psi/min equivalent to LRV of 3.0
Transmembrane pressure		
Filtrate turbidity	0.1 NTU	0.3 NTU
Disinfectant Residual, Low		
Disinfectant Residual, High		

b. Additional Operational Requirements

The following shall also be included in the Waterworks Operation Permit, Engineering Description Sheet:

- The permitted flux
- The maximum flux set by the manufacturer
- Maximum volume or percent of feed flow recirculated and corresponding VCF, if applicable
- The quality control release value (QCRV) established for the Non Destructive Performance Test (NDPT) that is related to 5.5-log removal efficiency.
- The direct integrity test must be conducted upon completion of any chemical cleaning process, diagnostic testing, scheduled maintenance, or repairs.
- The direct integrity test must be conducted, at least once each day on each unit that is in operation.

XIX. REPORTING AND RECORDKEEPING

a. Operational Control Criteria

An example Monthly operations Report form is in Appendix C. The appendix includes instructions for each item in the MOR. The MOR form and instructions are self-explanatory. The MOR form is an Excel spreadsheet and the instructions are in Word.

Summary reports shall be submitted with the Monthly Operations Report as note below as conditions dictate:

- Summarize all alarm and shutdown conditions
- Advise of all diagnostic testing and subsequent repair steps taken and follow up DIT results
- Summarize any DITs which were triggered by indirect integrity testing

Additionally, those applicable report forms associated with the various surface water treatment rules shall be submitted with the MOR.

Indirect integrity monitoring equipment required in Section XII is sufficient to meet the turbidity treatment technique reporting requirements.

- b. Sanitary Survey Report
Working Memo 851 contains appropriate sanitary survey report forms.
- c. Membrane Module Records
Detailed records for each membrane module should be kept according to each module serial number. Records should include dates, location, factory test data, repairs, replacements, etc. for each module.

XX. EXISTING MEMBRANE FILTRATION SYSTEM

Existing membrane treatment systems that have complied with Action Memo 1433 will not be required to comply with all aspects of this working memo. No changes to existing membrane treatment systems will be required until LT2 is effective.

Modifications to the previously approved membrane unit, the membrane barrier, or module configuration may require compliance with this working memo. Working memo compliance determination will be made case by case based on historical records of reliability, performance and public health protection. Routine maintenance, repair, or replacement with like kind generally would not necessitate compliance with this working memo.

For those MF & UF hollow fiber, positive pressure driven membranes approved prior to the effective date of this Working Memo, acceptance was based on an absolute cutoff of 1µm or less as demonstrated in various challenge tests and providing a 0.5-log inactivation in the disinfection treatment process. Failure was defined as loss of integrity. Loss of integrity was defined by the pressure based direct integrity test (previously referred to as the pressure decay test) initial pressure, and duration. Below are the minimum DIT criteria for resolution and sensitivity:

- o DIT alarm condition must be no greater than 0.3psi/minute
- o DIT shutdown condition must be no greater than 0.5psi/minute
- o DIT pressure must be in the 15 to 20 psi range.
- o DIT duration must be at least 5 minutes, not to include any delay for “stabilization”.
- o A DIT stabilization period is included in the DIT sequence of most polypropylene membranes due to the material being very hydrophobic and thus absorbing some air. Where the stabilization period is included in the sequence, the DIT pressure after the stabilization delay must be in the 15 to 20 psi range and the duration from the end of the stabilization period to the end of the decay test must be at least 5 minutes.

If the final DIT pressure is below 15 psi, a failed test results.

These criteria remain in effect unless the waterworks owner decides to submit data consistent with this guidance for product specific challenge test results and a quality control release value. Site specific criteria for the LRV, DIT performance criteria, indirect integrity monitoring performance criteria, etc. will be necessary.

The cross flow mode of operation was restricted to existing membrane treatment systems which demonstrated crossflow in the PER stage and were operating the crossflow at a maximum 10% recycle. This maximum recycle percentage shall continue to apply.

Replacement modules must be accompanied by documentation showing they meet a Quality Control Release Value consistent with the 3µm DIT resolution requirement and a LRV of 5.5.

Based on previous acceptance criteria (1µm absolute cutoff and 0.5-log inactivation), previously approved microfiltration and ultrafiltration, hollow fiber, positive pressure driven membrane filtration treatment works can be credited with 3-log removal of *Giardia* cysts or *Cryptosporidium* oocysts.

No credit is given for virus removal.

The direct integrity test must be conducted, as a minimum, once each day on each membrane unit that is in operation even if the unit is operated for only a fraction of the day. Each unit should be tested at approximately the same time each day.

Turbidity treatment technique compliance is based on a filtered water turbidity of less than or equal to 0.3 NTU in at least 95% of the measurements taken each month. Samples must be representative of the waterworks' filtered water. Additionally, the turbidity level of representative samples of a system's filtered water must at no time exceed 1 NTU. See Working Memo 869 for additional details.

END OF MEMO

APPENDIX A - PRELIMINARY ENGINEERING REPORT

A Preliminary Engineering Report (PER) is required by 12 VAC 5-590-200 of the *Waterworks Regulations*. The primary purpose of the PER is to demonstrate the adequacy of the proposal to safeguard public health and to comply with the *Waterworks Regulations*. The adequacy and applicability of the design must be demonstrated in the PER by presenting and evaluating operating data from a pilot study, full-scale plant study, or an ETV Report employing the proposed membrane product. See Appendix B for demonstration study and data collection requirements. The secondary purpose of the PER is to evaluate the technical, financial, and managerial capabilities of the potential owner to properly operate and maintain the proposed plant. In summary, the PER shall include the items in Appendices A and B, with emphasis on complying with disinfection and filtration requirements and showing that the owner will be able to provide proper O & M of the plant.

The first step in preparing a PER is to conduct a Preliminary Engineering Conference (PEC). The PEC will establish the method of demonstrating the adequacy of the design, the data necessary to justify the design, and the key elements of the PER. The PEC will determine which type of study will be required for the project. The project engineer may submit information to support eliminating the study requirement. The PEC should establish what data is to be obtained from the study(ies). Following the PEC, the engineer must submit study protocols and the PER key elements (in the form of a PEC summary) to ODW for approval prior to conducting the studies. Normally, these studies will be completed prior to the PER submittal since the studies will provide critical information for the project design outlined in the PER.

In the interest of increasing competition and reducing engineering design time and our review time, the project documents should take the *or equal* approach. Therefore, the PER should evaluate and determine whether the project will take the *or equal* approach. If it will, then the PER would designate those manufacturers that would be considered as *or equal* ; those manufacturers would be considered as pre-qualified bidders. The specifications would then contain requirements for all qualified bidders. If a bidder were not pre-qualified, an addendum to the PER would have to be submitted and approved prior to accepting their bid. If the successful bidder was not providing the equipment that was used as the design basis, then the engineer would have to submit an addendum for the necessary plan revisions.

**Suggested Key Elements
Of the
Preliminary Engineering Conference
And the
Preliminary Engineering Report**

1. Purpose of the proposal
 - a. Confirm appropriateness of the process relative to:
 - i. Regulatory compliance
 - ii. Source water treatability
 - iii. Feed water characteristics and limitations
 - iv. Level of confidence in the process
 - b. Compare effectiveness of alternatives
 - c. Establish design criteria
 - d. Establish performance levels
 - e. Establish operational goals, sensitivities, and constraints
2. Alternatives to compare
 - a. Operator in responsible charge and additional operating personnel class and attendance requirements
 - b. Operator in responsible charge duties during construction
 - c. Membrane specific challenge test protocol, results, and NDPT QCRV
 - d. Third party, membrane specific reviews, evaluations, approvals, certifications, listings, etc.
 - e. Waterworks design capacity
 - f. Effective daily production compatibility with distribution system effective storage
 - g. Prefiltration pore size and type
 - h. Pretreatment chemical conditioning
 - i. Performance comparison
 - ii. Operational cost comparison
 - iii. Compatibility with membrane
 - i. Membrane materials compatible with source water and prefiltration and pretreatment
 - j. Hydraulic configuration
 - i. Deposition or suspension
 - ii. Recycling
 - iii. Volumetric concentration factor
 - k. Post treatment
 - l. Supporting equipment
 - m. Instrumentation
 - i. Continuous indirect integrity monitoring
 - ii. Continuous point of entry monitoring
 - iii. Laboratory grade
 - n. Proprietary items associated with units
 - o. Waste disposal
 - p. Operator safety and environmental issues
3. Site specific or product specific treatment objectives or questions
4. Source water quality and quantity
 - a. Exceeds a turbidity level of 10 NTU monthly average over a one year period

- b. Organic content – dissolved, particulate, or hydrophobic
 - c. Continuous safe yield
- 5. Productivity Design Criteria
 - a. Flux – filtrate flow per membrane surface area
 - b. Maximum flux to prevent damage
 - c. Critical flux – further increase causes significant decrease in production
 - d. Flux at reference temperature of 20 degrees C
 - e. Flux at coldest anticipated temperature
 - f. Temperature normalized flux
 - g. Percent recovery – total required feed flow and total filtrate flow including process water and loss of production
 - h. TMP range
 - i. Maximum TMP to prevent damage and maximize membrane life
 - j. Minimum anticipated TMP over filtration cycle
 - k. Membrane resistance – total or intrinsic
 - l. Specific flux – temperature and pressure normalized
- 6. Membrane Units Design criteria
 - a. Membrane area at design flow
 - i. Total membrane resistance and maximum TMP at coldest anticipated temperature – or -
 - ii. Intrinsic membrane resistance and minimum anticipated TMP at coldest temperature
 - b. Number of modules per unit
- 7. Operational performance criteria
 - a. Energy requirements
 - b. Optimize for maximum membrane life
 - i. Flux
 - ii. Baseline TMP
 - iii. Backwash interval
 - iv. Chemical clean interval
 - v. Chemical usage
 - vi. Waste disposal
- 8. Operational control parameters
 - a. Direct integrity test sensitivity
 - b. Indirect integrity test method
 - c. Alarm set points
 - d. Shut down set points
- 9. Backwash Trigger
 - a. Time, flow volume, increase in TMP, or decrease in flux
 - b. Minimize down time and waste volume
 - c. Use of pressurized air, oxidants, bases, acids, surfactants, etc.
 - d. Backwash solution removal and verification
- 10. Chemical cleaning
 - a. Ability to restore unit to clean, baseline TMP
 - b. Heating chemical solution required
 - c. Softened and/or demineralized water required
 - d. Criteria for determining type and amount and sequence
 - e. Cleaning solution removal and verification
- 11. Influence of operational parameters on performance and production

12. Post-treatment
 - a. Chemical conditioning
 - b. disinfection
13. Waste disposal
 - a. Chemical and solids residuals disposal contact DEQ
 - b. Costs for various pretreatment and operational options
 - c. Chemical cleaning alternatives and backwash chemicals effects on waste disposal options
14. Sequence of construction
15. Schedule of performance verification period and full scale operation
16. Maintaining existing customer services
17. Project costs
 - a. Capitol
 - b. Operating
 - c. Monthly user fees
18. For existing waterworks – impact on the waterworks technical, financial, and managerial capabilities
19. Project inspection and management

APPENDIX B - DEMONSTRATION STUDIES

The cost of a pilot study and the potential cost savings from the data obtained should be part of the equipment selection criteria. If a report on a specific membrane treatment product has been issued from the National Sanitation Foundation/Environmental Protection Agency, Environmental Technology Verification (ETV) Program or equivalent, then a pilot or full-scale study may not be necessary.

In order to be considered a conventional process, the membrane alternatives must meet the requirements of this working memo. In doing so, a provisional operations permit will not be necessary. The first, primary consideration should be that the membrane module being considered must have been challenge tested in accordance with Section VIII.

a. Pilot Plant Study

A representative pilot plant study establishes design criteria, identifies operational sensitivities, evaluates effectiveness of alternatives, demonstrates treatability, and may include a challenge test, all based on short-term operational data taken during treatment of the proposed source water or treatment of water very similar to the proposed source water. The pilot study period is generally at least 30 days. Where historical source water data is not available, a longer testing period will generally be necessary to account for seasonal changes in source water characteristics. Alternatively, seasonal source water changes may be artificially induced to simulate worst case conditions. Finally, pilot plant studies require scale-up considerations in the final design. The EPA *Membrane Filtration Guidance Manual* should be consulted for further description of pilot testing considerations.

b. Full-Scale Study + Treatability Study

A second option for the demonstration study is a desktop study of a full-scale plant along with a treatability study of the actual proposed water source. The full-scale study establishes design criteria based on detailed review of design data and long-term operational data from an existing full-sized plant treating water very similar in characteristics to the source water proposed. Operational data available for review should satisfy the monitoring points and frequencies required for Demonstration Studies. Long-term operation should include seasonal variations, which would be expected to occur within 12 months. Use of a full-scale study as the basis for design would generally require a more conservative plant design than if a pilot study were used.

i. Treatability Study

A treatability study on the specific source will generally be required to establish the applicability of the proposed design to the specific source water, to establish operating conditions, and to establish a level of confidence in the operation and maintenance costs and resulting user fees. The treatability study duration is determined by the manufacturer and the engineer and is generally less time than a pilot study.

Site-specific treatability studies are required to verify:

- appropriate filtrate flux
- influent, effluent and filtrate pressures
- transmembrane pressures
- product water recovery
- rate of filtrate flux decline

- backwash frequency, duration and efficiency
- cleaning chemical type, sequence, frequency, duration and efficiency
- pre-filtration and membrane replacement frequencies.

The membrane system must be challenged to worst-case source water conditions to determine the limits of its performance. At least a seven-day continuous operation phase with 48 continuous hours of operation at or above the worst case source water characteristics of record may be necessary to make these determinations. Chemical cleaning shall be conducted at the end of the seven-day period to determine cleaning efficiency and resulting filtrate flux decline. Additionally, sacrificing a membrane to evaluate irreversible fouling may be necessary.

ii. Exception to Treatability Study Requirement

The treatability study requirement may be waived if the water used in the full-scale study is very similar to the proposed source water. Thus, there is the option to proceed to final design upon approval of the PER without further field studies. However, not performing a treatability study may increase the risk of ending up with an unreliable membrane design production capacity. Consequently, though this is a significant cost-saving option, there are some factors to consider before eliminating the treatability study. First, this option should only be considered where the source water quality is good and the design approach is conservative. Secondly, long-term historical source water data is necessary if a treatability study will not be conducted. Levels of water constituents such as microscopic particulates, minerals, dissolved constituents, etc. can greatly affect operation and maintenance costs. The fouling potential, pretreatment operating and maintenance, membrane replacement frequencies, and productivity design issues must be considered when considering whether to conduct treatability study and its duration. All these variables can impact the ability to reliably meet the design water demand by causing excessive backwashes, chemical cleaning, and/or membrane replacement. Therefore, these design risks must be considered and minimized even at the expense of increased cost of a treatability study.

c. NSF/EPA, ETV Report + Treatability Study

A third option for the demonstration study is a desktop evaluation of a NSF/EPA ETV Report and/or Verification Statement along with a treatability study of the actual proposed water source. The purpose of this desktop evaluation is to conclude whether the proposed membrane product is suitable for the project.

The goal of the EPA's ETV program is to provide credible performance data for commercial-ready environmental technologies to speed their implementation for the benefit of vendors, purchasers, regulators, and the public. The ETV Drinking Water System Center, run by NSF, conducts testing that determines and verifies performance of commercially ready drinking water treatment technologies for use in small communities. ETV does not rank technologies, compare technology performance, label or list technologies as acceptable or unacceptable, seek to determine "best available technology," or approve or disapprove technologies. NSF testing against the *Protocol for Equipment Verification Testing for Physical Removal of Microbiological and Particulate Contaminants* does not constitute an NSF Certification of the product tested. The membrane filtration verification testing plan contains both mandatory and optional testing protocols. Additionally, the protocol conforming to the challenge testing criteria was only recently developed and available for use in the verification program.

For an explanation of the treatability study requirements, see item b.i. above. A treatability study must always be conducted in conjunction with an ETV Report.

**Key Elements
Of
Demonstration Studies**

1. Method of demonstrating the adequacy of the design
2. Length of study
3. Responsibilities for operation and maintenance of all equipment
4. Monitoring points and frequency
5. Sampling schedule
6. Lab analysis procedures
7. Field analysis procedures
8. Challenge studies procedures
9. Description of unit under test
10. Support equipment
11. Discharge permit

**Monitoring Points and Frequency
For
Demonstration Studies**

Parameter	Sampling Points	Sampling Frequency	Sampling Technique
Turbidity	Source or Feed & Filtrate	Continuous	In-Line Monitor
Particles ≥ 2 μm	Source or Feed & Filtrate	Continuous	In-Line Monitor
Temperature	Feed	Daily	Grab
TOC	Source or Feed & Filtrate	5 Samples	Grab
SDS-TTHM & HAA5	Source or Feed & Filtrate	5 Samples	Grab
Hardness	Feed & Filtrate	Weekly	Grab
Alkalinity	Feed & Filtrate	Weekly	Grab
PH	Feed & Filtrate	Weekly	Grab
Iron & Manganese	Feed & Filtrate	Weekly	Grab
TDS & TSS	Source or Feed & Filtrate	Weekly	Grab
Free residual chlorine	Feed & Filtrate	2 hours	Grab
HPC	Source & Filtrate	Weekly	Grab
Total Coliform MPN	Source & Filtrate	Weekly	Grab
Phytoplankton	Source or Feed & Filtrate	2 Samples	Grab

OPERATIONAL			
Elapsed time meter	Membrane unit	At each startup	Operating time and Down time
Direct Integrity Test	Membrane Unit	For each process	See discussion below
Transmembrane Pressure	Membrane	Daily	Psi
Feed Flow	Rate & Total	Daily	gpm & gpd
Feed Pressure	Influent	2/day	Psi
Filtrate Flow	Rate & Total	Daily	gpm & gpd
Filtrate Pressure	Effluent	2/day	Psi
Recycle Flow	Rate & Total	Daily	gpm & gpd
Recycle Pressure	Pump Discharge	2/day	Psi
Cross Flow Velocity	Membrane	2/day	Fps
Process Flow	Total	Daily	Backwash Chemical clean
Waste Flow	Total	Daily	Calculation

The engineer should tailor the data needs to the specific membrane geometry and source water characteristics.

Monitoring Points and Frequency

Monitoring the source may not give an accurate representation of the concentration of a constituent being applied to the membrane. However, monitoring the concentration of the constituent at the feed point to the membrane may not give an accurate idea of prefiltration capabilities. A decision must be made as to the most appropriate monitoring location or locations for each constituent. Some constituents may require monitoring at three locations to determine the efficiency of each component and associated operational costs.

Turbidity

Purpose is to insure that adequate turbidity removals are occurring. Any turbidity that exceeds 0.1 NTUs in the filtrate water needs to be explained. Also, any fluctuations in the filtrate water turbidity need to be explained. Of particular concern would be significant turbidity fluctuations of the filtrate water, which corresponds to fluctuations of the feed water turbidities. Systems that use an air-assisted backwash may experience turbidity and particle count spikes when the membrane unit goes back into filtration.

pH

The pH must be controlled to protect the membrane material. Also, the entry point pH should be in the proper range to prevent corrosion in the downstream treatment units and distribution system and the Ph should be optimized for the disinfection process.

Total Coliform MPN

There are no criteria for coliform removal by membrane processes. However, some coliform bacteria are removed in membrane processes and the UF membranes would be expected to remove more than the MF. This data will be used to allow comparison of feed bacteria levels to filtrate levels. The feed and Filtrate samples should be taken at the same time to allow a valid comparison to be made. The statistical significance of the comparison will, of course, be greater the longer the study continues.

Particles

The purpose of the data gathered during the testing is to allow operating trends to be determined. The data gathered must be sufficient to determine appropriate operational control parameters. The sensitivity of the particle counters must be such that particles 3 microns and larger can be measured.

Temperature

The temperature data is appropriate to determine the flux of a membrane system vs. the viscosity of the water. Accurate temperature must be kept during the study to gauge the effect temperature will have on plant capacity.

Hardness

Hardness can affect the operation of membranes in two ways. Hardness is related to the stability of the water and corrosiveness of the water. Removal of an excessive amount of hardness may cause scaling problems that may lead to irreversible membrane fouling. The testing frequencies given assume that hardness removal by the membrane is negligible.

Alkalinity

Alkalinity is related to the stability of the water. The frequencies given here would be sufficient if alkalinity removal from the water is negligible. If the membrane used is susceptible to damage due to improper pH of the water, a higher frequency may be appropriate or a more sophisticated pH control would be appropriate.

Heterotrophic Plate Count

HPC (Standard methods 9215) – This test would be appropriate for membranes that may be adversely impacted by bacterial action. The test would show if the disinfection or oxidation processes used on the source water were eliminating heterotrophs that may damage the membrane material. The frequency of the testing should be adjusted according to how susceptible the membrane is to heterotrophic bacteria and the reliability of the source water pretreatment process if provided. Consideration should be given to using the more sensitive method employing R2A agar (S.M. 9215A.6.c.) in determining HPC.

Free Residual Chlorine

Free residual chlorine (FRC) – If prechlorination is not anticipated, the FRC would not need to be measured.

TOC

The TOC content should be broken down into the dissolved and particulate fractions. The dissolved fraction tends to adsorb onto the membrane material while the particulate fraction tends to clog the membrane pores. The dissolved carbon fraction should be characterized as either hydrophobic or hydrophilic. Hydrophobic organic material tends to foul membranes more readily and possibly more permanently. The use of SUVA/UV254 analysis may be useful.

Operational

Elapsed time meter

Operating times and down times are used to determine effective daily production and percent recovery.

Direct Integrity Test

Initially, direct integrity testing should be conducted several times daily until the test results have stabilized. Initial and final DIT pressure results and the test duration data are needed to determine the decay rate. The decay rate and the units log removal value should be determined.

Transmembrane Pressure

A maximum allowable transmembrane pressure and the expected TMP recovery must be determined to establish the TMP operating range. Also, the minimum expected TMP over the filtration cycle should be determined.

Filtrate Flow

The filtrate flow rate and total flow are necessary to determine the design flux, maximum flux, critical flux, flux at reference and coldest temperature, and specific flux. Each of these will be used for design capacity and ultimately for the waterworks permitted capacity.

Waste Flow

Establishing the volume of waste to be disposed of on a regular basis is important to insure that a properly designed waste holding/treatment/conveyance facility is considered.

Process Water and Elapsed Time

The amount of filtrate used for backwashing, chemical cleaning, etc. is needed to determine percent recovery. Percent recovery is determined using the total required feed flow and total filtrate flow including process water and loss of production or down time for processes to occur.

Phytoplankton

Feed and filtrate analysis of phytoplankton will assist in determining the type of contaminants fouling the membranes. Phytoplankton includes diatoms, algae, and pollen.

Alarm Condition

Any alarm condition must be detailed as well as the diagnostic testing and resulting repairs. Upon returning to service, a DIT must be conducted. Any DIT triggered by an indirect integrity test must be reported and detailed.

**APPENDIX C - INSTRUCTIONS FOR USING THE MONTHLY OPERATION REPORT FORM
for
Membrane Filtration Water Treatment Plants**

The monthly operation report form was developed to provide basic information to the operator and the Office of Drinking Water. It was developed assuming only one membrane unit is provided and includes some monitoring which may not be required at all membrane water treatment plants. These instructions only address items which may not be obvious to the operators and engineering staff.

Page 1 Instructions

- Chemical Table - Provide a list of water treatment chemicals in order to verify they are NSF approved.
- Sonic Testing Table - List the unit number, date tested and number of modules sonically tested. Only required at those plants equipped with sonic testing equipment
- Backflush Frequency - Frequency membrane unit performs a flush (i.e. every 60 minutes, etc.). This is typically set by the computer program.

Page 2 Instructions

Operations:

- Hours Operator at Plant – This is only the number of hours an operator is at the treatment plant performing required monitoring and/or performing maintenance at the treatment plant. Do not show the total hours the waterworks is manned.
- Hours Unit in Operation – This is the number of hours the membrane unit is in operation. This includes the time the plant is in the filtration mode and flushing mode. Do not include the time the plant is in the standby mode. Smaller units may have to calculate this value.

Water Volumes:

- Source/Raw Water Flow – This is the volume of untreated water being sent to the membrane unit. Additional columns may have to be added if the flow from the source is different from the flow sent to the membrane unit.
- Filtrate Volume – This is the volume of membrane filtered water being delivered to the disinfection process.
- Recirculated (Volume or Percentage of Feed Flow) – This is the volume or the percentage of the feed flow is which continuously recirculated back to the untreated side of the membrane as in the suspension mode hydraulic configuration. This column may be omitted if the membrane unit operates in the dead end mode and/or operates in a continuously waste mode.
- Waste Volume – This is the volume of water sent to the waste holding facilities for discharge and includes the volume of backflush water plus water which is continuously wasted when operating in the waste mode. The volume is typically determined from a waste meter and/or calculated by subtracting the Filtrate Volume from the Source/Raw Water Flow.
- Maximum Flux (gfd)– This is the maximum stabilized flux in gal/sq ft/day which the membrane unit operated during the day. This is not the instantaneous flux which occurs at unit startup or after a backwash.

Source Water Quality:

- Turbidity – Bench Unit – The daily turbidity as determined using the bench turbidimeter. Required at least 1/day.
- Turbidity – Inline Unit – Instantaneous – The turbidity indicated on the inline turbidimeter when performing a bench turbidity analysis.
- Maximum Turbidity – Inline Unit – The maximum turbidity recorded by the inline turbidimeter.
- Filtered Water Quality:
- Turbidity – Bench Unit – The daily turbidity (in milli NTU's) as determined using the bench turbidimeter. Required at least 1/day.
- Turbidity – Inline Unit – Instantaneous – The turbidity indicated on the inline turbidimeter (in milli NTU's) when performing a bench turbidity analysis.

Representative Maximum Turbidity – Inline Unit – The maximum turbidity (in milli NTU's) recorded by the inline turbidimeter during the operating daily excluding spikes resulting from physical and/or electrical interferences.

Filtered Water Quality

- Maximum Turbidity – Inline Unit (mNUT) – The maximum turbidity for the day which is stored in the laser nephelometer.
- Turbidity – Bench and Turbidity – Inline Instantaneous – Those readings should be taken at the same time to compare the accuracy of the inline unit with the bench unit.

Page 3 Instructions**Entry Point Water Quality:**

- Free Chlorine Residual – Inline Unit – Minimum – The daily minimum free chlorine residual recorded by the inline chlorine residual analyzer.
- Free Chlorine Residual – Inline Unit – Maximum – The daily maximum free chlorine residual recorded by the inline chlorine residual analyzer.
- Free Chlorine Residual – Grab Instantaneous – The free chlorine residual determined by the operator using the laboratory/bench free chlorine residual test equipment. Required at least 1/day.
- Free Chlorine Residual – Inline Unit – Instantaneous – The free chlorine residual indicated by the inline chlorine residual analyzer at the time the operator performs the free chlorine residual analysis using the laboratory/bench free chlorine residual test equipment.
- pH – The pH at the time the chlorine residual grab sample is taken.

Clearwell/Contact Tank:

- Chlorine Fed – The gallons or pounds of chlorine added to the filtered water.
- Chlorine Dosage – The calculated daily chlorine dosage based on the quantity of chlorine fed and the quantity of water treated with chlorine.

Pre-filter:

- Pressure Loss Across Pre-filter – This is the pressure loss as determined by pressure gauges on either side of the pre-filter units. The value reported is the difference between the upstream pressure gauge and the downstream pressure gauge. This pressure loss alerts the operator of when the pre-filter needs cleaning. This may be omitted if automated cleaning system is provided.
- Pressure Loss Across Pre-filter After Cleaning – This is the pressure loss after the pre-filters have been cleaned as determined by pressure gauges on either side of the pre-filter units. The value reported is the difference between the upstream pressure gauge and the downstream pressure gauge. This may be omitted if automated cleaning system is provided.

Membrane Units:

- Trans-Membrane Pressure – This is the instantaneous pressure across the membrane unit and is typically indicated on the membrane unit computer control system.
- Membrane Modules in Use – The number of membrane modules in operation.

Integrity Test:

- Starting Pressure – This is the starting pressure of the integrity test as reported by the membrane unit computer control system.
- Final Pressure - This is the ending pressure of the integrity test as reported by the membrane unit computer control system.
- Decay Rate Duration – The time which elapses between the starting pressure and the final pressure.
- Pressure Decay Rate – Provided by the membrane unit computer control system and is based on the starting pressure minus the ending pressure divided by the duration of the integrity test. Please note that most existing membrane plants do not currently have the capability to record and report the results of multiple integrity tests. Therefore, some existing plants will only be able to report the last integrity test.
- LRV – The corresponding log removal value

Page 4 Instructions**CIP Process:**

- Trans-membrane Pressure Before CIP - This is the instantaneous pressure across the membrane unit indicated on the membrane unit computer control system just prior to a CIP of the membrane unit.
- Trans-membrane Pressure After CIP - This is the instantaneous pressure across the membrane unit indicated on the membrane unit computer control system just after a CIP of the membrane unit. This will aid the operator in noting how well the membrane unit recovers after a CIP and will help the operator to determine when membranes may need to be replaced.
- Cleaning Solutions Used – List the various cleaning solutions, acids, alkali's, etc. used during the CIP process.
- Cleaning Solution Temperature – List the temperature of the cleaning solution which will verify the water heater is operating properly.
- pH of Rinse Water After CIP – The operator must report the pH and any other water quality test results on the water used to rinse the membrane unit after a CIP has been completed in order to confirm that all of the chemicals used to perform the CIP have been removed from the membrane unit before the membrane unit may go back into service. The specific analyses needed is dependent on the cleaning solutions used and will be specific for each plant.

Calibrations Completed

Date, unit calibrated, method of calibration, and results of the following equipment should be recorded:

- Laboratory equipment
- Dry chemical feeders
- Solution feeders
- Inline instrumentation
- Pressure transducers

Summary Report

The operator is to include a summary report of the maintenance performed on the membrane modules or the unit including:

- pinning of broken fibers
- replacement of modules
- repairs to module seals
- DITs which were triggered by indirect monitoring
- Alarm or shutdown conditions and follow up diagnostic testing and repair

APPENDIX D – MONTHLY OPERATIONS REPORT

Monthly Operations Report

for the

County
Waterworks
PWS ID #**Membrane Filtration
Water Treatment Plant**

For

Month: _____ Year: _____

Chemical	Kind of Chemical	
	NSF 60 compliant?	Used for?
Sodium Hydroxide	yes / no	
Chlorine	yes / no	
Fluoride	yes / no	
Other (name)	yes / no	
	yes / no	
	yes / no	
	yes / no	

Date Waste Basin Last Cleaned of Solids: _____

Sonic Testing		
Unit	Date	No. of Modules Tested

Backflush Frequency: _____

Number of Connections: _____ Population Served: _____

Signed: _____

Date Signed: _____

Print Name: _____

Title/Operator Classification: _____

Membrane Filtration Water Treatment Plant

[illegible]

Membrane Filtration Water Treatment Plant

[illegible]

DATE	Unit Cleaned	Trans-membrane Pressue Before CIP (psi)	Trans-membrane Pressure After CIP (psi)	Cleaning Solutions Used	Cleaning Solution Water Temperature	pH of Rinse Water After CIP	

DATE	UNIT	METHOD	RESULTS

[illegible]

APPENDIX E – WORKING MEMORANDUM REVISION DETAILS

The following changes were made to the Working Memo during the September 2006 revision:

I. PURPOSE

- change reflects that the EPA Guidance Manual has been finalized

IV. VIRUS REMOVAL CREDIT AND INACTIVATION REQUIRED

- disinfection required is 4-log inactivation of viruses and a 30 minute minimum free chlorine contact tank

VI. HYDRAULIC CONFIGURATIONS

- clarifications of deposition and suspension modes

VII. DESIGN AND OPERATION ISSUES

- removed generally recognized as safe
- replaced with otherwise acceptable to the Commissioner

VIII. PRODUCT SPECIFIC CHALLENGE TEST

- just clarifications

X. DIRECT INTEGRITY TEST

- added a suggestion that the test be conducted at the same time each day
- clarified the use of DIT sensitivity calculations for design purposes and for verifying actual DIT sensitivity and actual LRV during PERFORMANCE VERIFICATION period
- clarified the difference between initial, test, and final pressures

XI. DIAGNOSTIC TESTING

- clarifications
- added a note regarding need for adequate space for removal and replacing modules

XII. CONTINUOUS INDIRECT INTEGRITY MONITORING

- added basis for more stringent NTU standard for membranes
- clarified the NTU monitoring requirements to meet the turbidity treatment technique reporting and record keeping requirements

XIII. INSTRUMENTATION

- clarified that only filtrate NTU monitoring is required to be read and record
- clarified that all other monitoring is read only and recorded in the MOR
- clarified that filtrate turbidity monitoring of each unit shall be by the most sensitive method of turbidity monitoring available. Currently this method is by laser nephelometers. Other turbidity monitors will be evaluated and approved on a case-by-case basis.
- dropped the requirement for producing a hard copy showing daily trends and electronic backup of other data
- added a requirement for pressure gauge connection at each pressure transducer and the requirement for an accurate pressure gauge that can be calibrated

XVI. PERFORMANCE VERIFICATION

- generally reorganized and reformatted to clarify
- specifically, the performance report contents are now listed and have been somewhat expanded

XVIII. WATERWORKS OPERATION PERMIT SPECIAL CONDITIONS

- the percent recirculation in the cross flow mode and the corresponding VCF is added to the WOP

XIX. REPORTING AND RECORDKEEPING

- added for clarification that the instrumentation requirements of Section XII satisfy the treatment technique reporting requirements

XX. EXISTING MEMBRANE FILTRATION SYSTEMS

- clarified with less specificity, when modifications would require compliance with this working memo
- emphasized the requirement that the final DIT pressure must be ≥ 15 psi
- clarified the frequency and timing of the DITs

APPENDIX C. INSTRUCTIONS FOR USING THE MOR

- separately numbered the pages
- revised to reflect the revisions of the working memo

APPENDIX D. MONTHLY OPERATION REPORT FORM

- now a separate Appendix and separate file so that the form can easily be used
- changes reflect the revisions of the working memo